

# 2 DOOR REAR FENDER INSTALL ONLY

**\*\*DO NOT USE THESE STEPS ON 4 DOOR MODEL\*\***

1. Trim down the front three (3) bolt sleeves starting at a 1/4" and continuing in 1/4" increments. Test fit in-between each trim until you find your intended fitment OR until the flare is FLUSH with the body of the Jeep.

Trim using an angle grinder or cut-off wheel



2. At this point, make sure your rubber trim is installed



3. Install the supplied plastic spacers in-between the flare and the body of the Jeep on the rear four (4) bolt sleeves (see bottom photo) – then insert bolt through flare and spacer into fender hole of Jeep.

**\*You may need to add washers if fitment is not snug.**



**\*Rear four (4) bolt sleeves that require spacers**

