



3 Tube Side Bars for 4 Door JK
INSTALLATION INSTRUCTIONS

3101 W. FM 544
Wylie, TX 75098
866.342.0977
BLKMTNJeep.com

Part #BMAS-NB-3007B

Remove factory side steps – if applicable

Remove front and rear body mount bolts and nuts. These will be reused to install the side steps.
(See photos below)

Note: Black Mountain logo faces out. Shorter end faces front of Jeep and longer end faces rear of Jeep.

Install step bar using factory hardware. Do not tighten all the way down.

After both sides have hardware installed, tighten all down until flush.

